
Resetting a Voice Mail password – Samsung

Press Voice Mail button

When asked for a password **press * # 0000**

Password: 0000

Press 2 for Subscriber Administration

Enter subscriber #: Enter MB number followed by the # key.

Press 1 to accept.

Press 5 to Edit subscriber.

Press 1 to reset the password back to 0000 which is the default.

You can now exit Administration.

You can now log in to the mailbox with 0000 as the password.

To change the Password from 0000

Log in to the MB using 0000 as the password.

Press #71 to change the password.