
Instructions how to change date &/or time setting:

for

Samsung's Telephone Systems

IDCS-16, DCS-C, DCS, DCS-50si, iDCs-100, OS100, OS500,
OS7030, OS7100, OS7200 & OS7400

This is a two step process – follow as indicated. If you have any questions, please contact Sunrise Solutions at 410-573-0555.

1. Enable Customer programming:

- **DO NOT TAKE HANDSET OUT OF THE CRADLE** while performing programming.
- Press '**transfer**' (*display will read: program mode*)
- Press '**200**' (*display will read: enable Cus. Prog.*)
- Press '**12341**' (*display reads: enable & you will hear a few beeps*)
- Press '**transfer**' (*display will revert to: date & time*)

2. Set Date & Time:

- **DO NOT TAKE HANDSET OUT OF THE CRADLE** while performing programming.
- Press '**transfer**' (display will read: program mode)
- Press '**505**' (display will read
- OLD: xxxxxxxx:xxxxw;
NEW: wmmddy:hhmm (These are variables – see below)
- Enter data for '**w**' day of week (*see #'s below*)
0=Sun, 1=Mon, 2=Tues, 3=Wed, 4=Thu, 5=Fri, 6=Sat
- Enter data for '**mm**' for month in two digit format (*Range: 01-12*)
- Enter data for '**dd**' for day of month in 2 digit format (*Range: 01-31*)
- Enter data for '**yy**' for last two digits of the year (*ex: 2010 = 10*)
- Enter data for '**hh**' for hour in **2 digit military format** (*Range: 00-24*)
(i.e. If are entering 1pm – use 13)
- Enter data for '**mm**' for minute in 2 digit format (*Range: 00-59*); (*you will hear a few beeps*)
- Press '**Transfer**' to exit

You have now changed the date/time on the phone system!