


Operator Panel

The **Operator Panel** page provides a graphical view of the PBX state and activity, acting as an operator console.

1. Open the UC^X Web-based Configuration Utility
2. From the **PBX** tab, select **Operator Panel**

The graphical panel is broken into sections:

- Extensions
- DAHDI Trunks
- SIP/IAX Trunks
- Areas
- Conferences
- Parking Lots
- Queues.



You can see at a glance:

- What extensions are busy, ringing, or available
- Who is talking and to whom
- Message waiting indicators and message counts
- Conference status
- Queue status (number of calls waiting)
- Parked Channels

You can perform these actions via drag & drop:


- Originate calls
- Hang-up calls
- Transfer calls

Registered devices have orange background. Devices that are not registered have light yellow background.

Extension Filter

- ✓ The Extension Filter capability is available for software releases 4.5 and up.

You can limit the number of extensions displayed on the Operator Panel by clicking the **Extension Filter** link.



Enter the list of extensions to be displayed in the **Extension Filter** box.

The box can be expanded by clicking and dragging on the bottom right corner.

Use space or comma to separate extensions in the list. Use "-" for a range. Multiple lines are allowed.

The **Extension Limit** sets the maximum number of extensions to be displayed. The supported values are between 0 and 9999.

Use 0 to disable the limit.



Note, there is a known performance issue when displaying more than 50 extensions at a time.